

Nokeval
made to measure



Kombi-Sky

Manual

ID10830 V13 11.11.2020
Firmware 1.0-1.0

Contents

Introduction	2
Installation	3
Operation	5
Maintenance	8
Specifications	9
Warnings	11
Manufacturer	11
Declaration of conformity	12

Introduction

Kombi-Sky is an economical multi-sensor indoor air quality (IAQ) transmitter developed from the Kube-RHT series. Kombi-Sky measures temperature, humidity, total volatile organic compound (TVOC) concentration, differential pressure and carbon dioxide (CO₂) concentration. Kombi-Sky model uses a LoRa based Nokeval Sky radio, which means that this device is not compatible with the LoRaWAN infrastructure. If LoRaWAN is needed, choose the Kombi-LoRaWAN device instead of Kombi-Sky.


Before using the 433 MHz radio, make sure it is legal in your country.

Installation

Mounting

Select the installation place so that air can flow freely on all sides of the transmitter and that it represents the air that is to be measured. Avoid heat sources and direct sunlight. Place the device to the measuring location with one of the following ways:

- Mount the wall holder with two universal countersunk screws (ST 2.5 or ST 3.0). Use applicable length depending wall material. In correct orientation, the wall holder has its hooks pointing upwards. Attach the Kombi-Sky to the holder.



- Place the Kombi-Sky freely on any surface with the bottom facing down.

Power supplies

The Kombi-Sky is powered with three LR6 (AA) batteries.

The device is supplied with batteries already installed, so it is ready to be used.

The Kombi-Sky can alternatively be powered with an external supply. When an external power supply is used, the batteries can be omitted or used as a backup supply. Use the micro USB socket to connect an external supply into the device.

The Kombi-Sky indicates the powerup by blinking the led next to the micro USB socket.

Settings

The Kombi-Sky works with its default settings and no parameter configuration is normally required. However, if it is necessary to change the settings of the device, it can be done with Nokeval's MekuWin software (available for free at www.nokeval.com). Following procedure should be followed in order to get access to the settings:

- Connect a micro-USB cable to the connector, and the other end of the cable to a computer.
- If Windows requests for a driver, download it at www.nokeval.com > Support, unzip it to a temporary folder, and show that directory as the location for the driver. If there are problems during the installation, try pushing the button every 5-15 seconds or keeping it pressed so that the Kombi-Sky will not shut down its USB port.
- Launch the MekuWin program.
- In MekuWin, choose the right COM-port from the Ports-menu. If the port is not visible, try pushing the button on the Kombi-Sky to wake up the port.
- From the Port settings -menu, choose Protocol = ModbusRTU, Address = 1.
- Click Direct.
- A new window will open for the settings.

The configuration menu includes the following settings:

- Protection
 - Describes password protection status "None", "Locked", "Unlocked".
- Password input/setup
 - Unlock protection or change password. See "Protecting the settings" section below for details.
- Period
 - Time between measurements with options from ranging 5 minutes to 6 hours. Default is 30 min.
- Sky
 - See the Detailed radio settings

Commissioning the radio

To get the radio working with your receiver, adjust the following settings in the Sky menu to match the corresponding settings of your receiver, otherwise the communication will fail:

- Network (default 1)
- Effort (default 4)
- Channel (default 1)
- Key (default empty)

The address of this Kombi-Sky can be seen in the Address box. The address is factory set and can't be changed here.

If you want to ensure that every measurement is delivered despite of radio collisions and disturbances, set the following settings (this will typically double the battery consumption):

- Quality = Buffering (default Unidirectional, which means send and forget)
- Destination = the radio address of your (nearest) receiver

To learn about the more detailed radio settings, see the chapter Detailed radio settings on page 5.

Protecting the settings

To protect the settings from being easily adjusted, the configuration menu provides a password box. The password can be formed using up to 16 characters. From the next MekuWin session after the password is set, the settings cannot be adjusted without knowing the password.

If the protection status is “Locked”, changes will not be saved to the device. Write the correct password in the “Password input” field and press enter to unlock the protection.

If the protection status is “Unlocked”, the settings and password can be changed. The menu will become locked again after the MekuWin session is closed.

Note that the password cannot be reset by the user. If the password is forgotten, the password reset can only be made by the manufacturer. Please make sure that the password is remembered if changed.

Operation

After the Kombi-Sky is successfully installed, it operates on its own. However, there are some considerations that are good to know when using the Kombi-Sky.

RHT measurement

Temperature is given in °C. Humidity is given in %RH.

TVOC measurement

An auto calibration is necessary for the TVOC sensor. A prolonged exposure to high TVOC concentrations will affect the baseline of the sensor and the sensor will give incorrect readings until the baseline is corrected. The auto calibration can work properly only if the Kombi-Sky is exposed to a fresh air at least some hours after the prolonged exposure. TVOC concentration is given in ppb.

dP measurement

The pressure difference between the outlets is measured using the air flow. The direction of the air flow determines the sign of the reading. If the outlet in the left-hand side is in higher pressure than the outlet in the right-hand side, the reading is positive and vice versa. The pressure difference is given in Pa.

CO2 measurement

An auto calibration is necessary for the carbon dioxide sensor. Without it, the sensor will drift over time and eventually give incorrect readings. The auto calibration can work properly only if the Kombi-Sky is exposed to a fresh air at least some hours during each week. In practice, the room must be unoccupied, and its ventilation must be switched on. CO2 concentration is given in ppm.

Detailed radio settings

Network: To prevent mixing the different networks (and users) data, the network address should be set to a value not used nearby. All the devices within one network must share the same value. The receiver

will only accept packets that have the matching network address. If an encryption key is used, it is not necessary to use a unique network address. Default 1.

Effort: This single setting controls the LoRa bandwidth and spreading parameters as in the table below. The bigger the value, the longer the range. But it will consume more battery and radio band. Increasing the effort one step will approximately add 2.5 dB in the link budget, but also double the battery consumption caused by the radio.

The selectable Efforts are tabulated below. The LoRa bandwidth and spreading factor are mentioned for curiosity. The estimated ranges are for reference only, in real world the range depends heavily on the objects on the radio path. No range can be guaranteed, a single metal wall may stop the radio signal totally.

Effort setting	LoRa bandwidth	LoRa spreading factor	Estimated indoor range	Estimated real world outdoor range 30 dB/decade
1	250 kHz	7		1100 m
2	250 kHz	8		1300 m
3	250 kHz	9		1600 m
4 (default)	250 kHz	10	30...300 m	1900 m
5	250 kHz	11		2300 m
6	250 kHz	12		2800 m
7	125 kHz	12		3500 m

The default Effort is 4, which is good for many tasks. Each device in the network must share the value.

The Effort setting can be set to Custom position; then it is possible to set the bandwidth and spreading parameters independently, as well as adjust the frequency steplessly within 433.3 to 434.5 MHz. Normally this should not be necessary.

Power: The transmission power; 10 means the maximum power and each step reduces one dB. A lower value should be selected to conserve battery and to avoid disturbing other users of the band whenever possible. However, this setting will not affect the battery consumption as much as the Effort setting, which means that the first mean to lower the battery consumption should be lowering the effort if possible. While each device in the network must share the Effort setting, the Power can be adjusted individually. In practice, the Effort is defined by the most distant device, and the Power of the nearer devices can be lowered.

Channel: The radio frequency channel. If several LoRa/Sky networks exists within the same area, a different frequency should be selected for each network. The radio frequency is $433.3 + 0.2 \text{ MHz} \cdot (\text{channel}-1)$, i.e. the first channel is 433.3 MHz, second 433.5 etc. The channel 4 uses 433.9 MHz which is the most crowded frequency on this band, so it should be avoided.

Quality: This setting has three options affecting the reliability of the packet delivery:

- Unidirectional (default): This device will transmit each reading once not expecting any acknowledgement. If the packet is lost due to a collision with another transmission or any disturbance, it is lost.
- Bidirectional: After transmitting a packet, this device will listen for an acknowledgement from a receiver and retransmit up to two times if not getting acknowledged. If there is no acknowledgement, this device will discard the packet and try only once for the next time. This setting increases the probability of successful delivery significantly but does not guarantee it.

- **Buffering:** This device will keep retransmitting each reading until acknowledged. The readings will be buffered until delivered as far as the buffer is not full. The buffer can hold approx. 1000 packets (400 in devices manufactured before autumn 2019). When the buffer is more than half full, the measurement intervals will be temporarily increased to slow down the filling of the buffer.

Each device can have an individual choice.

Destination: When using the Bidirectional or the Buffered quality, the receiver that is supposed to acknowledge must be manually defined. Enter the radio address of the receiver here. The system can have several receivers, each picking the same radio packets, but only one must be selected to acknowledge to avoid collisions.

Key: An authentication and encryption key for the radio. If an authentication is not desired, leave this blank. Then it is quite easy to eavesdrop and disrupt the radio traffic. To get a secured operation, enter any text string (up to 16 characters). Use the same key in the receiver, and consequently in all the other transmitters. Once set, the key can't be viewed in the menu, it is replaced by ***.

Address: The radio address of this device. Can't be changed.

Buffer: Displays how many percentages of the buffer is used. Should be 0 when the network is operating smoothly. This is for viewing only, can't be manually adjusted.

Quantity channels

The Kombi-Sky sends the measurement quantities using the logical channels as in the table below. These channel numbers are used when configuring the device for the Ovaport service or any other type of receiving system.

Channel	Physical quantity	Unit
1	Temperature	°C
2	Relative humidity	%RH
4	TVOC concentration	ppb
5	Differential pressure	Pa
6	CO2 concentration	ppm

Monitor menu

In MekuWin, the Mon-menu can be used to monitor the measurement readings. The sensors are kept continuously on. The values update at the rate the sensor can produce new readings.

Cal menu

The calibration menu settings are only for the manufacturer use. They are not explained in this manual.

Maintenance

Checking the status

Press the button to check the status of the Kombi-Sky. The led located next to the micro USB socket will indicate the status:

- If the led blinks green, everything is fine, and the remaining battery capacity is estimated to be over 20%.
- If the led blinks red, the remaining battery capacity is estimated to be below 20%.
- If the led doesn't blink at all, device isn't working properly.

Replacing the batteries

- Remove the device from the wall holder by pushing it upwards.
- Remove the two screws from the bottom of the device and open the cover.
- Replace the batteries with three new LR6 (alkaline AA) batteries observing the polarity.

Cleaning

If there is visible dust inside the device, blow it away with pressurized air while avoiding too strong pressure. The enclosure exterior can be wiped with a damp cloth, but no drop of liquid must enter the device.


Specifications

Environment

Storage temperature	-40...+80°C, without batteries, non-condensing
Operating temperature	-30...+60°C, non-condensing
Protection class	IP20
Enclosure material	ABS+PC, white painted

Measurements

Weight	210g, with batteries
Dimensions	105 x 75 x 48 mm



Power supply

Batteries	3 pcs LR6 (AA 1.5 V alkaline). For the estimated battery life, high quality batteries should be used, e.g. Energizer EN91.
Typical battery life	3 years with 30 minutes transmission interval
External	Micro USB type B, 5 ± 0.5 V, max 200 mA, no suspend function

Measuring and data transmission

Interval	Configurable: 5min / 10min / 15min / 20min / 30min / 1h / 2h / 3h / 4h / 6h
Radio	Nokeval Sky radio technology
Antenna	Internal
Frequency band	433.05 – 434.79 MHz
Transmission power	Max +10 dBm E.R.P.
Range, line-of-sight	Depends on installation location and environment, in good conditions 10 km
Range, indoor	Typically 30...300 m, depending on materials and structures

Temperature measurement

Sensor	High-accuracy semiconductor sensor, Swiss
Measurement range	-40...+125°C
Accuracy	Typically ±0.1°C (+20...+60 °C)

Humidity measurement

Sensor	High-accuracy semiconductor sensor, Swiss
Measurement range	0...100 %RH
Accuracy	Typically ±2 %RH (+0...+80°C, 0...100 %RH)

Carbon dioxide concentration

Sensor	NDIR sensor
Measurement range	400...5000 ppm
Accuracy	Typically ±45 ppm + 3% rdg
Autocalibration	Must see fresh air (unoccupied room) once a week

Total volatile organic compound concentration

Sensor	Semiconductor sensor, Swiss
Measurement range	0.3...30 ppm
Accuracy	Typically ±15%

Differential pressure measurement

Sensor	High-accuracy flow sensor, Swiss
Measurement range	-125...+125 Pa
Accuracy	Typically ± 0.08 Pa + 3% rdg

Warnings



The device must not be disposed in household waste. Observe local regulations concerning the disposal of electrical waste. The device may contain a battery.

Manufacturer

Nokeval Oy
Rounionkatu 107
FI-37150 Nokia

Phone +358 3 342 4810 (Mon-Fri 8:30-16:00 EET)
WWW <http://www.nokeval.com/>
Email sales@nokeval.com



Declaration of conformity



EU Declaration of Conformity

Object of declaration: Wireless measuring device
Model/Type: Kombi-Sky
Description: Wireless 433.92MHz temperature, humidity, CO2, differential pressure, TVOC transmitter based on LoRa-modulation.

Manufacturer: Nokeval Oy
Rounionkatu 107, 37150 Nokia, Finland

www.nokeval.com
tel. +358 33424 800
support@nokeval.com

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The object of the declaration described above is in conformity with the relevant Union harmonization legislation:

Directive (RED) 2014/53/EU
Directive (RoHS) 2011/65/EU

The conformity is given based on the following harmonized standards:

RED:	EN 300 220-2 V3.1.1 (2017-02) EN 301 489-1 V2.1.1 (2017-02) EN 301 489-3 V2.1.1 (2017-03)
EMC:	EN 61326-1:2013
LVD:	EN 61010-1:2010
RoHS:	EN 50581:2012

Product is marked with CE mark to indicate compliance.
Product is designed and manufactured in Finland.

Signed for and on behalf of Nokeval Oy:

At Nokia 04.03.2020

Jani Vähäsöyrinki, Managing Director

www.nokeval.com